



TOKYO SOKUTEIKIZAI Stock List

Part No : A15 use for Rotary Switch : DPP01 0 02N0RCBC

Part No : A30 SWITCH PUSHBUTTON

Part No : BS60

Part No : DPP01 0 02N0RCBC

Part No : DPP02116J20CB

Part No : DPP02116J20RCB

Part No : DPP02116J20RCB SWITCH

Part No : RSF5T-3M2E-100B